

How to install the new driver for your RX Carbon unit.

Make sure that your RX Carbon unit is **not** connected when you go through the below steps:

1. Click on the following link in order to access the new driver (available on the True Heading website):
<http://www.trueheading.se/files/document/products/ais/aisrxcarbon/USB%20Drivers%20RX%20Carbon%20units.zip>.
2. Save the compressed file on your PC.
3. Extract the folder. Do not forget where the files will be saved/extracted to.
4. Open the folder "USB Drivers RX Carbon units".
5. Open the folder "USB Drivers Krypton".
6. Double click on the file "CDM20828_Setup".
7. Follow the instructions that come up during the installation.
 - a. You will be asked to "extract all files". Click on "Extract".
 - b. Click on "Next" and then "Finish".
8. If the system i.e. your PC tells you that the installation was not done correctly, click on redo the installation. Follow the instructions again from #4.
9. Connect your RX Carbon unit.
10. Do not forget to make the necessary settings in your unit (plotter and/or PC) that shall receive the AIS targets.

NOTE! The RX Carbon does not send any NMEA information out from the RX Carbon if the RX Carbon is not receiving any AIS targets. I.e. if no VHF antenna is connected, or that any AIS targets are received, the RX Carbon will not send any AIS targets to your e.g. plotter and/or PC.